

## Riviera Gazebo

HPGAR141



The Large Gazebo will arrive in via fed ex ground. Please remove all contents before starting assembly. You should have: 4 upright extensions, 4 uprights, 4 end gables, 8 decorative corners, 1 decorative crown, 10 rafters, and the following hardware:

64 - 1/4" x 1/4" Bolts    22 - 1/4" x 3/4" Bolts    10 - 1/4" x 1/2" Bolts

### Installation Instructions:

**Step One:** Attach each of the 4 upright extensions to a corresponding upright using the B bolts.

**Step Two:** Assemble the end gables. Attach front right to front left and back right to back left using the B bolts.

**Step Three:** Lay the upright extensions on the ground. Attach an end gable to each upright. Repeat the process in the back using Bolts

**Step Four:** Stand the uprights up with the gables attached. Space the two sections approximately 6 ft apart and attach the side supports with the Bolts

**Step Five:** Attach the decorative roof support, insert the Bolts but do not tighten them.

**Step Six:** Begin placing rafters by starting at the front on one side. Insert the Bolts and nuts in the bottom on the side support but do not tighten. Do not put the Bolts and nuts in the top along the roof support; you will do this last when you have bolted all 10 rafters to the side supports. The top of the rafters will rest against the roof support.

**Step Seven:** After you have finished bolting all the rafters to the side supports, bolt the rafters to the roof supports. Two bolts and two nuts for two rafters. Do not tighten. Once you have all the bolts and nuts in the rafters go thru and tighten all the bolts at the top and bottom.

**Step Eight:** Attach the decorative corner pieces as show in the diagram using A Bolts.

